12. BSM300
LABEL, ACCESSORIES

1

CHEMICAL PIPING CHART

PRESSURE GAGE
PRESSURE VALVE
CHEMICAL TANK
POWER SPRAYER
STRINER
STRAINER
WATER VALVE
BOOM NOZZLE

ARROW SHOW THE DIRECTION OF WATER, OR CHEMICAL.

2

HOW TO USE WATER VALVE

MAKE SURE THAT THE VALVE IS OPEN BEFORE OPERATION

WATER VALVE
OPEN
CLOSE

HOW TO CLEAN SUCTION STRAINER

AFTER SPRAY OPERATION,OPEN CAP,REMOVE STRAINER, CHECK AND CLEAN IT.
WHEN YOU INSTALL STRAINER,MAKE SURE THERE IS O-RING THEN CLOSE CAP.

OPEN
SUCTION STRAINER
O-RING

4

⚠ WARNING

- PLEASE WEAR CLOTHES WHICH FITS YOU. PLEASE PREPARE PROTECTION CLOTHES, PROTECTION GOGGLES,RUBBER GLOVES, AND WORK BOOTS,AND WORK WITH SAFE CLOTHES.
- DO NOT TAKE THE WATER DIRECTLY FROM DRINKING WATER SOURCE OR LAKE WHERE LIVING THINGS ARE BREEDED.
- PLEASE FORM A SPRAY PLAN SO THAT CHEMICAL DON'T REMAIN.
- MAKE SURE TO ATTACH AND DETACH THE UNIT WITH EMPTY CHEMICAL TANK.
- PLEASE AVOID SUDDEN STARTING, SUDDEN TURNING,SUDDEN BRAKING, FOR FEAR OF OVER-TURNING.

3

INSTRUCTION

WHEN YOU PAUSE OR FINISH SPRAYING.
ROTATE PRESSURE ADJUSTING DIAL COUNTERCLOCKWISE FULLY TO DECREASE PRESSURE THEN STOP PTO.

5

⚠ CAUTION

CAUTION FOR HANDLING CHEMICAL
- PLEASE READ THE INSTRUCTION MANUAL OF CHEMICAL CAREFULLY AND USE CORRECTLY.
- PLEASE ADJUST SPRAY HEIGHT BY THREE PERSON FOR SAFETY. YOU MAY BE INJURED IF BOOM IS FALLEN.
- MAKE SURE OF EXISTENCE OF OIL BEFORE STARTING.

7

← LUBRICATION

9

P T O
580~820rpm

11

6

CLOSE ↑	CLOSE ↑	CLOSE ↑
RIGHT NOZZLE	CENTER NOZZLE	LEFT NOZZLE
↓ OPEN	↓ OPEN	↓ OPEN

8

OPERATION PRESSURE 0.5~2.0MPa

10

CAUTION
BE CAREFUL IN OPETATING LIFE UP LEVER OF LOWER LINK. TOO HIGHER LIFT CAUSES HITTING AND DAMAGE TO TRACTOR AND SPRAYER.

13

MADE IN THAILAND

12

BSM300
Ⓜ MARUYAMA

15　　**16**　　**17**

14

Manual

18