




### Parts List

- |                    |                       |   |                                   |                    |                      |
|--------------------|-----------------------|---|-----------------------------------|--------------------|----------------------|
| Ax4PCS<br>ST6x50mm | Bx4PCS<br>Φ10xΦ6x50mm | Cx4PCS<br>Φ13xΦ6x1.0mm<br>Metallic Washer | Gx4PCS<br>M6x20mm                 | 4PCS<br>M8x20mm    |                      |
| Hx4PCS<br>M5x20mm  | Ix2PCS<br>M6x35mm     | Jx2PCS<br>M6x10mm                         | Kx2PCS<br>M6<br>Angle Adjust Knob | Lx4PCS<br>(18x5x8) | 1PCS<br>Bubble level |




Maximum installation  
distance  
600x400mm  
400x400mm

### TOOLS NEEDED(NOT INCLUDED)



### STEP 1

The Horizontal plate  
FIX WITH Six screws  
in the wall;



### STEP3

Hang the TV onto the wall

