

This image displays 38 numbered labels for a Komatsu excavator, organized as follows:

- Labels 1-4:** Model identification labels showing "BSM84OSLT", "BSM104OSLT", "BSM124OSLT", and "BSM154OSLT".
- Label 5:** Brand name label "丸山" (Maruyama).
- Label 6:** Another brand name label "丸山" (Maruyama).
- Labels 7-8:** Hydraulic hose or pipe components.
- Label 9:** "取扱要領" (Operation Manual) with safety instructions regarding work stoppage and PTO engagement.
- Label 10:** "PTO回転数 330" (PTO Rotation Speed 330).
- Label 11:** "ブーム給油箇所" (Boom Lubrication Points) with instructions for applying grease to joints and rollers.
- Label 12:** "常用圧力 2MPa" (Normal Pressure 2MPa).
- Labels 13-15:** Operational diagrams: "ノズル操作" (Nozzle Operation), "ワイヤーの張り調整" (Wire Tension Adjustment), and "三方コック取扱" (Three-Way Valve Operation).
- Labels 16-18:** Hydraulic oil level indicators and controls, including "注油" (Fill Oil) arrows and a vertical level gauge labeled "H" and "L".
- Labels 19-21:** Simple geometric shapes: a square, a rectangle, and a circle.
- Labels 22-23:** System diagrams: "配管系統図" (Piping System Diagram) and "油圧配管系統図" (Hydraulic Piping System Diagram).
- Labels 24-38:** A series of numerical labels from -100 to -1500, likely representing pressure or flow rates.